

Midea logo and product information for the pressure cooker. Includes model numbers (MY-SS5050P, MY-SS5051P, MY-SS5050XM, MY-SS5057P, MY-SS5069P), contact number (400-8899-315), and address (Guangdong Midea Electrical Manufacturing Co., Ltd.).

安全警告 (Safety Warnings) section. Includes icons for safety warnings and detailed text instructions regarding safe use, handling, and maintenance of the pressure cooker.

安全警告 (Safety Warnings) section. Continues with safety instructions, including warnings about using the pressure cooker with children, handling hot parts, and proper cleaning procedures.

安全警告 (Safety Warnings) section. Focuses on electrical safety, including warnings about using the pressure cooker with damaged power cords, using it in wet areas, and ensuring proper grounding.

产品简介 (Product Introduction) and 使用说明 (Instructions) section. Includes a detailed diagram of the pressure cooker with labeled parts (lid, float valve, gasket, etc.) and a step-by-step guide for basic cooking operations.

使用说明 (Instructions) section. Provides detailed instructions for various cooking functions, including '快速入门' (Quick Start) for soups and '预约功能' (Reservation Function) for delayed cooking.

使用说明 (Instructions) section. Details the '快速功能' (Quick Function) for rice and other dishes, and provides information on the '快速功能烹饪' (Quick Function Cooking) process.

使用说明 (Instructions) section. Covers '中途开盖排气' (Midway lid opening and venting), '浓香模式' (Rich Flavor Mode), and '再加热' (Reheat) functions.

使用说明 (Instructions) section. Details '中途开盖排气' (Midway lid opening and venting) and '浓香模式' (Rich Flavor Mode) with specific steps and diagrams.

清洁保养 (Cleaning and Maintenance) section. Provides instructions for cleaning the lid, gasket, and inner pot, along with diagrams showing the correct cleaning methods.

服务指南 (Service Guide) section. Includes '产品参数' (Product Parameters) table and '电路原理图' (Circuit Diagram) for the MY-SS5050P/S050XM model.

服务指南 (Service Guide) section. Includes '产品参数' (Product Parameters) table and '电路原理图' (Circuit Diagram) for the MY-SS5057P/S05069P model.

服务指南 (Service Guide) section. Details '故障处理' (Troubleshooting) for common issues like '不能合盖' (Lid won't close) and '不能开盖' (Lid won't open), and includes an '环保清单' (Environmental List).

服务指南 (Service Guide) section. Focuses on '食品接触清单' (Food Contact List) and provides a table of materials used in the pressure cooker, such as stainless steel and aluminum.

保修卡 (Warranty Card) section. Includes the Midea logo, a table for user information, and details regarding the warranty and service network.

入门手册技术要求 (Technical Requirements) table. Lists specifications for the product, including model numbers, materials, and dimensions.

产品参数 (Product Parameters) table. Lists technical specifications for various models, including rated voltage, power, capacity, and working pressure.

故障处理 (Troubleshooting) table. Lists common faults and their corresponding solutions, such as '不能合盖' (Lid won't close) and '不能开盖' (Lid won't open).

食品接触清单 (Food Contact List) table. Lists materials used in the pressure cooker and their corresponding standards.

食品接触清单 (Food Contact List) table. Continues the list of materials and standards for food contact parts.