



12.It is forbidden to use products as heat preservation and heating equipment for animals 13.It is forbidden to face the product to the power socket, and the heater shall not be **Warning:** In order to ensure the safety of use and avoid injury and property damage placed directly under the power socket.

to you or others, you must comply with the following safety precautions. Failure to 14.Do not immerse the product in water. This heater shall not be used around bathtubs, observe safety warnings and misuse may lead to accidents. sprinklers or swimming pools. This product does not take into account the use of appliances by unattended children and the disabled, and children's playing with appliances. This situation may lead to [note] matters that may cause minor injury or property damage 1.Before use, please check whether the voltage used is the same as the voltage marked [warning] Indicates safety matters that may lead to death or serious injury. on the product. [warm prompt] Indicates other safety matter. 2.When the product is in normal use or idle, it should be more than 1.5 meters away from **[note]** Indicates safety matters that may cause minor injury or property damage.

the fire source and kindling, and avoid direct sunlight. 3.Because the coverage or incorrect placement of the heater will cause a fire, it is not allowed to use the programmer, timer or other devices with automatic power on to use the product. 4. When the product using, the power cord should be placed behind the machine body. Placing it in front of the machine body will overheat and damage it, and even cause safety accidents. 5. When using the product, in order to avoid burns, please do not let bare skin directly contact the surface of the air outlet.

6.Before cleaning this product, be sure to turn off the power switch and unplug the plug, and then clean it after the product is completely cooled. 7.Children, the elderly or patients who have lost the ability to take care of themselves should use the product under the supervision of adults to prevent accidents. 8.For high mounted heaters, the instructions shall specify that the heater must be installed at a height of at least 1.8m above the ground. [tips] other safety matters

2.After cleaning and maintenance, be sure to wait until it is fully dry before being powered on for use or collection. 3.Please unplug the power cord when it is not used for a long time. It is recommended to wrap it in the original package and store it in a dry place. 4. Avoid bumping or scratching the product to avoid surface coating damage and rust. 5.The heater shall be filled with a certain amount of special oil. If the oil container needs to be opened during repair due to leakage, the work can only be completed by the manufacturer or contacted with the after-sales service agent of the manufacturer. 6. When the heater is discarded, it shall comply with the relevant provisions on oil

7.During initial heating, there may be a slight sound, which is a common phenomenon

8.The heat expansion and cold contraction at the joint of the heat sink of some products

may cause a few fine lines on the paint surface, which is a normal phenomenon and can

1.This product is only suitable for indoor use, not outdoor use.

when the heat transfer oil is heated, and it can be used safely.

注:说明书图片仅供参考,具体以包装箱内实物为准。

be safely used.

Reminder of other precautions during use 1.For reasons of safety and energy saving, the , the machine will switch off automatically if it has been in continuous operation for more than 15hours without operation.Note: if the user uses the product timed shutdown function, the timed shutdown time operation is

2.No matter in which mode, the temperature sensor has short circuit or open circuit protection, the digital screen displays "E2" or "E1" which is always on, and pressing any key will not work. The buzzer buzzes for 10 times. 3.No matter in which mode, the temperature sensor has short circuit or open circuit protection, the digital screen displays "E2" or "E1" which is always on, and pressing any key will not work. The buzzer buzzes for 10 times. 4.When the machine is turned on and the indoor ambient temperature th exceeds 50  $\,^\circ\mathrm{C}$  , the system will turn off all outputs, the buzzer will sound for 10 times, and the digital screen will display "FF" and flash at the frequency of 1 time / s. pressing any key will not work. The protection can only be exited after power failure. 5.In order to prevent scald risk, the product has an automatic adjustment function.

When the ambient temperature is high, it will automatically downshift, and when the


Fin as-heat ———


Castor wheel


water tank ———


This section describes the contents and importance of safety matters to prevent personal injury or property damage to users or others. Please read the text on the basis of fully understanding the following contents, and be sure to observe the safety precautions described.


temperature is low, it will automatically upshift.














本机使用的电源为 220V~,使用插座的承载能力不得低于 10A,使用前请确认电源插座额定电流符合要求,否则应更换插座。 若产品出现断电保护,无法继续使用时,电源线插头,静置机器,待冷却后重新指符。 发插头,可恢复正常使用;若此时机器 ▲ 使用前需要先检查电源线以及插头是否破损。如果电源软线损坏,为了避免危险,必须由制造商、 其维修部或类似部门的专业人员更换。

禁止用插(拔)电源线插头的方法代替功率开关的开放下电源线插头运输,有产品出现战障,谓立即关机开放下电源线插头运输,接近用插(拔)电源线插头的方法代替功率开关的开放下电源线插头运输,将近特约维修点请专业人员维修。非专职人员或者未授权修理人员,不得自行修理或改造本机。 用部件定时进行通、断的电路。

全型 禁止在易燃、易爆,受热易变形、变色、变质的物体附近或有严重粉尘的地方使用。 地方使用。使用产品时应放置平稳,请不要翻倒或 禁止用细的金属丝或其它异物插入机内任何孔隙,倾斜。以免造成触电事故。

禁止与其他大功率电器共用插座,严禁直接拉着 禁止把产品作为动植物的保温、加热设备。 电源线移动产品。 

⚠ 【注意】可能造成轻伤或者财产损失的事项 



长期不用时请将电源线插头拔下,建议最好用原包装包好,收藏于干燥的地方。 ● 避免碰伤或划伤产品,以免表面涂层损伤而生锈。

accidents.

[warning] key safety matters

1.The power supply of this machine is 220V-, and the bearing capacity of the socket

should not be less than 10A. Please confirm that the rated current of the power socket

2.If the product has power-off protection and cannot continue to be used, please unplug

the power cord plug, leave the machine still, and plug in the power cord plug again

after cooling, so as to restore normal use; If the machine still cannot be used at this

time, please shut down immediately, unplug the power cord and send it to the nearby

special maintenance point for professional maintenance. Non full time personnel or

unauthorized repairmen are not allowed to repair or transform this machine by themselves.

3.Check whether the power cord and plug are damaged before use. If the power cord

is damaged, in order to avoid danger, it must be replaced by professionals from the

maintenance. Non-specialist personnel or unauthorized repairmen are not allowed to

5.It is forbidden to plug (unplug) the power cord to replace the power switch on and off.

6.In order to avoid the danger caused by the false reset of the thermal circuit breaker,

the appliance cannot be powered by an external switching device, such as a timer or

connected to a circuit that is regularly turned on and off by general components.

8.It is forbidden to use near inflammable, explosive, easily deformed, discolored and

9.It is forbidden to use in places where there are hanging objects that are easy to fall,

vulnerable to impact or unstable placement. When using the product, it should be placed

10.It is forbidden to insert fine wire or other foreign matter into any hole in the machine

11.lt is forbidden to share sockets with other high-power appliances, and it is forbidden

4.If the product is faulty, please shut down the machine immediately, unplug the

power cord and send it to a nearby special maintenance point for professional

manufacturer, its maintenance department or similar departments.

repair or transform this machine by themselves

7.Do not cover the heater to avoid overheating.

deteriorated objects or places with serious dust.

stably, please do not overturn or tilt.

and tilt it. To avoid electric shock accidents.

to directly pull the power cord to move the product.


meets the requirements before use, otherwise the socket should be replaced.


■ 本加热器要充灌定量的特殊油类。如果因泄露在修理时需要打开盛油容器,则该项工作仅能由制造厂来完成或与制造厂的售后服务代理接洽。 ● 当废弃加热器时,要符合油类处理的有关规定。 🥊 初始加热时,可能会有轻微声响,属导热油被加热时发生的常见现象,可放心使用。 ● 个别产品散热片接缝处受热胀冷缩的影响可能会导致漆面出现少许细纹,属正常现象,可放心使用。

● 使用中其他注意事项提醒


考虑到用户安全使用取暖产品和节能原因,若机器连续工作超过 15 小时,且过程中无操作,机器将自动关机。注:如果用户使用产品定时关机功能,则优先执行定时关机时间操作。 ● 无论在何种模式,温度传感器出现短路、开路保护,数码屏显示"E2"或者"E1"常亮,按任何键均不 ● 当处于开机状态时,室内环境温度 TH 超过 50°C时,系统关闭所有输出,蜂鸣器常鸣 10 次,数码屏显示"FF"并以 1 次 / 秒的频率闪烁,按任何键均不起作用。只有断电才能退出保护。


本节描述了安全事项的内容及重要性,以防止对使用者或他人造成人身伤害或财产损失。 • 请在充分理解上面内容的基础上阅读正文,并请务必遵守所描述的安全事项。


















说明书技术要求											
物料编码	16157000001703										
产品型号	HY22A1-PL 公差 ±2.0mm										
客户名称	PELONIS 成品尺寸 145x210mm										
材质	□ 80g双胶纸 □ 128g铜版纸 ✓ 其它: 128g哑粉纸										
印刷颜色	□ 单色 V 两色 □ 四色(CMYK) □ 四色(CMYK)+专色										
专色数量	▼ 无										
表面处理	□ 无 □ 光油 □ 光胶 ▼ 哑胶 □ 其它:										
成形方式	<ul><li>□ 单张</li></ul>	)									

						128g哑粉纸					
际记	外数	分区	更改文件号	签名	年、月、日		1 4	209	エイソノーレし		
设计	蓝锦先	2022-8-18	标准化			阶段标记			重量	比例	
校对								В	重量	1:1	
审核								Ь	<b>半</b> 里	1.1	  -
工艺	蓝锦先	2022-8-18	审批			共 1 张 第 1 张					

HY22A1-PL\_SMS-01